



## The PC keyboard for medical technology



### CleanBoard

- ⊙ PC keyboard with mouse pad and numeric keypad
- ⊙ Mouse pad can be switched on/off
- ⊙ Sealed membrane surface/IP65
- ⊙ Disinfection interval monitoring through LED display
- ⊙ Ergonomic and robust plastic housing
- ⊙ Acoustical feedback through speaker, with volume control



# CleanBoard

The PC keyboard for medical technology



# CleanBoard

The PC keyboard for medical technology

Special requirements call for special solutions. The **CleanBoard from Hoffmann + Krippner** is ideally suited for deployment in the area of medical technology.

With an IP65 rating, the **keywi** PC keyboard is splashproof, making cleaning easy and fast.

The ultra-flat design-housing delivers a product that is not only resistant to all common disinfectants but is also particularly attractive.

This also makes the **keywi** PC keyboard an interesting option for medical workplaces where a lot of data has to be entered.

- ⊙ Easy and fast cleaning
- ⊙ No chance for viruses and bacteria
- ⊙ Plug & Play – without installation

## Available models

- The following country versions are available:  
Germany – Switzerland – USA – GB
- Further country versions on request!

**NEW**

Your personal CleanBoard  
We are also happy to deliver the CleanBoard badged with your company logo. Just ask our Sales Team for a quotation.

## TECHNICAL PROPERTIES

- ⊙ PC keyboard with mouse pad and numeric keypad
- ⊙ Mouse pad can be switched on/off
- ⊙ USB connection/Cable length: 160 cm
- ⊙ Dimensions: L 410 x W 215 x H 25 mm
- ⊙ Sealed membrane surface/IP65
- ⊙ Ergonomic and robust plastic housing
- ⊙ Acoustical feedback through speaker, with volume control
- ⊙ Easy to clean and disinfect
- ⊙ Disinfection interval monitoring through LED display
- ⊙ Key stop function during routine wipe disinfection
- ⊙ Pleasant typing sensation/ Compatible with 10 finger typing
- ⊙ Storage temperature: - 4°F to 140°F
- ⊙ Operating temperature: 32°F to 122°F

## CLEANING AND DISINFECTION ADVICE

1. Basically, the keyboard can be cleaned using any standard disinfectant and/or cleaning agents. "Self-mixed" agents should only be used after checking first with the manufacturer.
2. The keyboard should not be immersed in disinfectant or cleaning agents. Immersing the keyboard in any other liquids is also not permitted.
3. Please take note of any relevant statutory regulations and guidelines.
4. Please take note of the handling advice given by the disinfectant and cleaning agent manufacturer.

The list of tested disinfectants and advice on cleaning and disinfection is available under [www.clean-keyboards.com](http://www.clean-keyboards.com).

The recommendations and advice on cleaning our products are made, based on both internal and external research.



- keywi USA  
A division of Hoffmann + Krippner Inc  
200 Westpark Drive  
Peachtree City, GA 30269  
Phone: (770) 487-1950  
[sales@keywi-usa.com](mailto:sales@keywi-usa.com)

[www.clean-keyboards.com](http://www.clean-keyboards.com)